

Product Data Sheet


DIAION™ CRB05

DIAION™ CRB05 is a glucamine type chelating resin. It has a high selectivity for borate ion and higher capacity than DIAION™ CRB03. It is recommended for borate separation process from various solutions, including brines, sea water and wastewater.

Product

Grade Name	DIAION™ CRB05
Type	Chelating Resin
Matrix	Styrene-DVB, Highly Porous

Chemical Structure



Functional Group	N-Methyl Glucamine
Ionic Form	Free Base

Specification

Whole Bead Count	-	95 min.
Total Exchange Capacity	meq/mL	0.95 min.
Water Content	%	43 - 53
Particle Size Distribution on 850 μm	%	10 max.
Particle Size Distribution thr. 300 μm	%	1 max.
Effective Size	mm	0.35 min.
Uniformity Coefficient	-	1.6 max.

Typical Properties

Shipping Density	g/L	750
Mean Particle Size	μm	550
Adsorption Isotherm of Boric Acid	mg/mL-R	25
Particle Density	g/mL	1.13
Total Swelling (FB to Cl)	%	11

Recommended Operating Conditions

Maximum Operating Temperature	°C	100
Effective pH Range		6 - 10
Minimum Bed Depth	mm	800
Service Flow Rate	BV/h	5 - 20
Eluate		HCl
		H ₂ SO ₄
Eluate Concentration	%	HCl 2 - 4
		H ₂ SO ₄ 1 - 5
Eluate Level	g/L	50 - 100
Eluate Flow Rate	BV/h	1 - 3
Regenerant		NaOH
Regenerant Concentration	%	NaOH 2 - 4
Regenerant Level	g/L	20 - 40
Regenerant Flow Rate	BV/h	1 - 3
Total Rinse Requirement	BV	10 - 20

1 BV(Bed Volume)=1 m³/m³-resin

Hydraulic Characteristics

The approximate pressure drop at various temperatures and flow rates for each meter of bed depth of DIAION™ CRB05 resin in normal down flow operation is shown in the graphs below.




Fig. 1 Pressure Drop of CRB05




Fig. 2 Bed Expansion of CRB05

Notice

DIAION™ is a registered trademark of Mitsubishi Chemical Corporation. The information contained herein is believed to be true and accurate, but all data, recommendations and suggestions are provided without guarantee, since the conditions of use are beyond our control and can affect the performance and properties of our products. The user is solely responsible for confirming that our product is suitable for the intended end use, and for compliance with all legal regulations and patents. Other than compliance with published Mitsubishi Chemical Corporation specifications agreed to pursuant to a signed writing during the warranty period, and except as required by law, MITSUBISHI CHEMICAL CORPORATION AND ITS AFFILIATES MAKE NO WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, OR ANY WARRANTY ARISING OUT OF A COURSE OF DEALING, CUSTOM OR USAGE OF TRADE. If a product is found to be defective during the warranty period, user's sole remedy and our sole obligation is, at our option, replacement of the affected product or refund of the purchase price. Except as required by law, we are not liable for any damage, harm or loss resulting from our product, whether direct, indirect, consequential, incidental or special, and irrespective of legal theory asserted, including strict liability, contract, warranty, or negligence.