

Product Data Sheet

DIAION™ USMT100

DIAION™ USMT100 is a mixed resin with strongly acidic cation exchange resin, DIAION™ UBK08HUP, and strongly basic anion exchange resin, DIAION™ UBA120OHUP. It is used for non-regenerable mixed bed for ultrapure water.

Product

Grade Name	DIAION™ USMT100		
Type	Mixed		
Matrix	Styrene-DVB, Gel		
Functional Group	Sulfonic acid / Type I (trimethyl ammonium groups)		
Ionic Form	H ⁺ / OH ⁻		
Chemical Equivalent Ratio	1 / 1		

Specification

Component		Mixed resin	
ΔTOC	ppb	2 max.	
Outlet Resistivity	MΩ·cm	18 min.	
Component		Cation exchange resin	Anion exchange resin
		DIAION™ UBK08HUP	DIAION™ UBA120OHUP
Salt Splitting Capacity	meq/mL	1.8 min.	1.0 min.
Water Content	%	50 - 56	62 - 70
Mean Particle Size	μm	570 - 670	570 - 670
Uniformity Coefficient	-	1.10 max	1.10 max.
Ionic Form Conversion (H ⁺)	eq%	99.9 min.	-
Ionic Form Conversion (OH ⁻)	eq%	-	90 min.
Ionic Form Conversion (Cl ⁻)	eq%	-	1 max.
ΔTOC	ppb	20 max.	20 max.
Outlet Resistivity	MΩ·cm	12 min.	15 min.

Typical Properties

Component		Mixed resin	
Shipping Density	g/L	710	
Component		Cation exchange resin	Anion exchange resin
		DIAION™ UBK08HUP	DIAION™ UBA120OHUP
Mean Particle Size	μm	630	630
Particle Density	g/mL	1.20	1.07
Total Swelling (Na ⁺ to H ⁺)	%	9	-
Total Swelling (Cl ⁻ to OH ⁻)	%	-	24

Recommended Operating Conditions

Maximum Operating Temperature	°C	60
Operating pH Range		0 - 14
Minimum Bed Depth	mm	800
Service Flow Rate	BV/h	10 - 60

1 BV(Bed Volume)=1 m³/m³-resin

Hydraulic Characteristics

The approximate pressure drop at various temperatures and flow rates for each meter of bed depth of DIAION™ USMT100 resin in normal down flow operation is shown in the graphs below.




Fig. 1 Pressure Drop of USMT100

Rinse Performance




Fig. 2 Resistivity versus Rinse Volume for USMT100
Flow rate : SV 30 (15 L/hr), Resin volume : 500 mL-R




Fig. 3 Delta TOC versus Rinse Volume for USMT100
Flow rate : SV 30 (15 L/hr), Resin volume : 500 mL-R

Notice

DIAION™ is a registered trademark of Mitsubishi Chemical Corporation. The information contained herein is believed to be true and accurate, but all data, recommendations and suggestions are provided without guarantee, since the conditions of use are beyond our control and can affect the performance and properties of our products. The user is solely responsible for confirming that our product is suitable for the intended end use, and for compliance with all legal regulations and patents. Other than compliance with published Mitsubishi Chemical Corporation specifications agreed to pursuant to a signed writing during the warranty period, and except as required by law, MITSUBISHI CHEMICAL CORPORATION AND ITS AFFILIATES MAKE NO WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, OR ANY WARRANTY ARISING OUT OF A COURSE OF DEALING, CUSTOM OR USAGE OF TRADE. If a product is found to be defective during the warranty period, user's sole remedy and our sole obligation is, at our option, replacement of the affected product or refund of the purchase price. Except as required by law, we are not liable for any damage, harm or loss resulting from our product, whether direct, indirect, consequential, incidental or special, and irrespective of legal theory asserted, including strict liability, contract, warranty, or negligence.